WASHER/DRYER CONTROL PANEL PARTS

WASHER/DRYER LAUNDRY SYSTEM

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1		Panel, Control
	3396683	White
	3396684	Almond
2	3390688	Spacer- Foam Pad (2)
3	3390689	Bracket, Control (Includes Illus. 2)
4	3946439	Timer, Washer
6		Dial (Washer)
	3403097	White
	3403098	Almond
7		Knob, Timer (Washer)
	3358417	White
	3358420	Almond
8		Knob, Control (2)
	3358435	White
	3358436	Almond
9	3388706	Resistor
10		Knob, Push To Start
	3396161	White
	3396164	Almond
11		Knob, Timer (Dryer)
	3396150	White
	3396151	Almond
12	96435	Screw
13	3360910	Switch, Pressure
14	3348352	Switch, Temperature
15	3390631	Screw, 10-16 x 3/8
16	660936	Switch, Push To Start
19	3393934	Timer, Dryer
21	3389453	Bracket, Hinge (2)
22		End Cap- Right Hand
	3389456	White
	3389457	Almond
23	3398980	Harness - Dryer
23B	62889	Receptacle, Power (Washer)
23C	3395683	Connector (Motor-Dryer)
24	3390604	Clamp, Harness
25	3390422	Clip, Harness (2)
29		End Cap- Left Hand
	3389464	White
	3389465	Almond
30	3390663	Screw, 10-16 x 1/2

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3389249	Nut, Push (4)
2	3391901	Switch, Door
3	98234	Clip, Ground
4		Panel, Front
	3392547	White
	3392548	Almond
5	3390735	Seal, Door
6	3392563	Door, Rear
7		Door, Front
	3387872	White
	3387873	Almond
8	3388229	Retainer, Toe Panel (2)
9	3387242	Bearing & Seal
11	696144	Strike, Panel
12	697773	Screw, Door Switch Mounting (2)
13	3393008	Screw, 10-16 x 1/2 (2) (Front Panel To Side Panel)
14	3392538	Catch, Door
15		Handle, Door
	3389522	White
	3389523	Almond
16	3390902	Clip, Door Hinge (2)
17		Panel, Toe
	3388958	White
	3388959	Almond
19	342055	Screw
20	3389247	Hinge & Pin, Door (2)
23	694091	Screw, (Door Handle)

DRYER CABINET AND MOTOR PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	660658	Clamp, Motor Mounting (2)
	343481	(Alt.)
	685441	(Alt.)
2	3395655	Motor, Main Drive (60 Hz.)
3	3398948	Wire, Jumper
4	3394881	Switch, Broken Belt
5	3388895	Bracket, Motor
6	3389847	Panel, Rear
7	343641	Screw, 10-16 x 1/2
8	3387673	Cover, Terminal Block
9	697776	Screw, 10-32 x 1/2
10		Panel, Side
	3389264	White, LH
	3389265	Almond, LH
	3389256	White, RH
	3389257	Almond, RH
11	3390631	Screw, Ground
14	3394081	Wire, Broken Belt Switch
15	3389231	Clip, Front Panel (2)
16	98234	Clip, Ground
17	3391639	Bracket, Bulkhead
18	233520	Washer, Thrust
19	690997	Tri-Ring
20	661570	Belt, Drive
21	3391087	Pulley, Motor (60 Hz.)
22	3389332	Bracket, Idler
24	3390026	Base, Dryer
25	3387374	Spring, Idler
26	3389683	Cove, Transition Panel (Black)
27		Panel, Transition
	3397881	White
	3397882	Almond
28	3389537	Top, Dryer
30	3389682	Spacer (2)
31	3393722	Bracket, Terminal Block
32	687104	Cord, Power
33	3390631	Screw
34	3387485	Screw 10-16 x 5/8
35	98129	Screw
36	690261	Block, Terminal
37	3390631	Screw
38	3389420	Bolt, Shoulder
39	3388672	Pulley, Idler
40	3393720	Clip, Nut
42	687000	Relief, Strain
43	3392285	Screw, Set
44	692400	Nut, Push-In
45	3390192	Catch, Magnetic
47	693304	Screw And Washer
49	3390722	Shield-Console To Drum
50	279393	Screw Kit (For Terminal Block)
51	279318	Terminal, Tinned & Brass (3)
52	3391408	Lever, Snap Switch

DRYER BULKHEAD PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3387460	Shaft, Roller
2	90767	Screw, 8A x 3/8
3	343641	Screw, 10-16 x 1/2
4	3394984	Door, Lint Screen
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	3391906	Seal, Lint Duct
8	3359452	Nut (2)
10	3389449	Baffle, Drum (3)
11	3390459	Pipe, Exhaust
13	3391685	Seal, Transition Duct To Lint Duct
14	3387749	Element, Heater
15	279457	Wire Kit (For Heater Element Wiring Harness Repair)
16	3387709	Nut, Hex (2)
17	3387809	Bulkhead, Rear
18	3387459	Washer, Support
19	3387707	Shaft, L.H. Thread
20	690997	Tri- Ring
21	3397588	Support, Roller
22	3387230	Screw, 10-16 x 3/4
23	3394985	Housing, Outlet
24	697814	Seal, Drum Front To Lint Duct
25	3389448	Assembly, Drum
26	697777	Screw, 11-16 x 7/8 (6)
27	697694	Seal, Drum
29	3390646	Screw, 8-18 x 5/16 (2)
31	697770	Seal, Cover Plate
33	3391293	Seal, Transition Duct
35	3390935	Clip, Duct Locator
37	697772	Wheel, Blower Harness (3)
38	3389445	Duct, Transition (Includes Illus. No.33)
39	697366	Plate, Blower
40	3394986	Spring, Lint Screen Door
42	3387134	Thermostat, Internal-Bias
43	695240	Screw, 8-18 x 1/2
44	697363	Housing, Blower
45	3388909	Lint Duct Assembly (Includes Illus. No. 7 & 13)
46	697715	Box, Heater
47	3389946	Thermal Cutoff
48	696397	Fixed, Thermostat
49	3389647	Bracket, Heater Mounting
50	3391927	Limiter, Thermal
51	3389644	Screen, Lint
52	697767	Grille, Outlet
53	697557	Bulkhead, Front

DRYER SUPPORT AND WASHER HARNESS PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3396691	Harness - Washer
1A	3350130	Plug, 3 Way (Uses Terminal 94614)
1B	3347243	Connector, 5 Way (Uses Terminal 352088)
1C	352089	Block, Disconnect - Timer (Uses Terminal 352088)
1D	3350211	Receptacle, 3 Way (Uses Terminal 94614)
1E	62505	Block, Disconnect (Uses Terminal 352088)
2	3388851	Channel Assembly (Left Hand Side)
3	3388850	Channel Assembly (Right Hand Side)
4	3390609	Shield, Harness
5	3350124	Hose, Pressure Switch
6	3390496	Clip, Harness
7	343641	Screw, 10-16 x 1/2 (6)
8	685463	Kit, Grounding
9	132848	Screw, 10-24 x 1
10	685449	Wire
11	120361	Nut, Hex
12	22965	Strap, Grounding
13	9415810	Bolt, 5/16-18 x 1/2 (4)
14	3393930	Nut, Hex (4)
15	3394350	Shield, Front
16	3390336	Shield, Thermostat
17	3393008	Screw, 10-16 x 1/2
18	3391249	Clip, Harness (2)
19	358736	Insulator
20	358763	Terminal, Female
21	374230	Block, Terminal
22	352088	Terminal, Female
23		Terminal,
	94613	Male
	94614	Female
24	63523	Protector, Harness

WASHER TOP AND LID PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1		Lid, Top
	3351652	White
	3351653	Almond
2	93770	Bumper, Lid (2)
3	3351355	Screw And Washer
4	343641	Screw, 10-16 x 1/2
5	692400	Nut, Push-In (2)
6		Top, Console
	3349798	White
	3349799	Almond
7	357572	Clip, Grounding
11	21258	Hinge, Bearing (2)
12	3356311	Screw And Washer
13	358684	Strike, Lid
14	54583	Hinge, R.H.
15	54584	Hinge, L.H.
17	3355458	Switch, Lid
18	90016	Clip, Wire (4)
19	3390193	Strike, Magnetic
22	3390481	Locator, Top
23	19119	Bumper, Lid Hinge

WASHER CABINET PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3349770	Clip, Spring Top (2)
2	3349768	Bracket, Vacuum
3	62863	Screw, Mixing Valve Mounting (2) (10-16 X 3/8)
5	3360388	Valve, Water Mixing
6	370451	Clamp, Hose
7	3352236	Hose, Water Inlet (Vacuum Break To Mixing Valve)
8		Panel, Side (2) (Same Panel Used On Left And Right Side)
	3349455	White
	3349456	Almond
9	3350745	Brace, Front Panel
10	3353841	Hose, Drain
12	660975	Plug, Top To Cabinet (2)
	689587	(Alt.)
	694010	(Alt.)
13	356739	Connector, Hose
14	356138	Clamp, Hose
15	3349673	Bracket, Valve
16	387606	Thermister, Inlet
17	371503	Clamp, Hose
18	3350145	Shield, Lid Switch
19	3349323	Base, Cabinet
20	3388857	Bracket, Base
21	371507	Clamp, Hose
22	3394083	Clip, Front Panel (2)
23	3349310	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27		Panel, Front
	3349499	White
	3349500	Almond
29	358594	Foot, Rear (2)
30	3350144	Bracket, Lid Switch
32	352292	Nut, Push-In (2)
33	9415810	Screw, 5/16-18 x 1/2 (2)
34	389102	Foot, Front (2)
35	124829	Nut, Jam (2)
36	3349493	Panel, Rear (Washer)
37	343641	Screw, 10-16 x 1/2
38	3349697	Rail, Back Top
39	3350135	Spring, Lever Bracket
40		Shield, Corner
	3390608	Right Rear
41	3393930	Nut, Hex (2)
42	352292	Nut, Push-In (2)

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	388951	Brake And Drive Tube (Complete) (Refer To Brake & Drive Tube Parts Page For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3351343	Clutch (Complete)
6	388190	Band And Lining (Includes Illus. 7 & 8)
7	387712	Spring, Clutch
8	62646	Cap, Clutch Spring (2)
9	3360630	Gearcase (Complete) (Refer To Gearcase Parts Page For Further Breakdown)
10	3357334	Screw, 5/16-24 x 5/8
11	62611	Plate, Motor Mount To Gearcase
13	3364003	Coupling, Motor & Isolating
14	661600	Motor, Main Drive
15	357021	Capacitor, Motor Start
16	3946532	Shield, Motor
17	62863	Screw, 10-16 x 3/8
18	3363892	Pump, Complete
19	62700	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
23	3362089	Shield, Tub To Motor
24	3387485	Screw (2) #10-16 x 5/8
25	357030	Clamp, Capacitor
26	3355454	Clip, Anti-Rattle

MACHINE BASE PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	343641	Screw, Bracket Mounting (10-16 x 1/2)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring, Suspension (3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
9	3350506	Retainer, Hose
10	63134	Ring, Sound Deadening
11	63806	Retainer, Suspension Spring
12	3349332	Screw, Shoulder (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	62602	Pad, Base
19	3349343	Base Assembly (Includes Illus. 6, 7, 18 & 26)
21	3349749	Restrainer, Base
22	3349340	Washer (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)

AGITATOR, BASKET AND TUB PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3355758	Cap, Agitator
2	3947410	Cam Driven
3	387091	Dog, Agitator (4)
4	358237	Screw
5	387094	Cap, Barrier
6	3349610	Mover, Agitator Clutch
7	3351014	Spacer, Thrust
8	3349578	Agitator
9	63851	Tub Ring
10	3359585	Gasket, Tub Ring
11	3352234	Basket
12	21366	Nut, Spanner
13	3361948	Filter, Plate
14	3349292	Tub
16	389140	Block, Drive
17	383727	Gasket, Centerpost
18	3350124	Hose, Pressure Switch
19	3348855	Seal, Inner Cap
20	371502	Clamp, Hose (2)
21	62731	Hose, Tub To Pump
23	64002	Seal, Agitator
24	3350834	Dispenser, (Accessory Only, Not Included in Model)

GEARCASE PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



GC–215C

1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

BRAKE AND DRIVE TUBE PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	62647	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

	285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

WASHER WATER SYSTEM PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	285321	Sleeve Kit, Plastic Drain Hose (Contains 2 Sleeves)
2	65349	Clamp, Hose (2)
3	16272	Connector, Straight
4	285320	Siphon Break Kit (Not Included)
5	661575	Hose, Corrugated Plastic Drain (5-1/2 Ft.)
	661577	Hose, Corrugated Plastic Drain (10 Ft.) (Not Included)
6	3357027	Nozzle, Drain Hose
9	3357331	Clamp, Hose
10	356739	Connector, Hose
11	3354858	Hose, Inlet (2)
12	285442	Connector Kit, Plastic Drain Hose

MISCELLANEOUS PARTS

For Models: LTE6234AW2, LTE6234AN2
(White) (Almond)



1	3356714	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose
3	356138	Clamp, Hose
5	3357331	Clamp, Hose (Upper Drain)

LITERATURE PARTS

LIT3397510	Instructions, Installation
LIT3396301	Guide, Use And Care
LIT3398986	Label, Wiring Diagram
LIT3397738	Tag, Energy Guide

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

350938	Primer, Gray
350930	White
350956	Almond

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

OIL

350572	Oil, Gearcase (16 Oz.)

LUBRICANT

285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

ACCESSORIES

279823	Side Exhaust Kit
694609	Exhaust Deflector Kit